


EQUIPMENT INSTALLATION GUIDE DS2278







DS2278 scanner configuration procedure

- 1. ChronoMEDIC Production must be closed.
- 2. Connect the gray wire to the base.
- 3. Plug the base into the USB port on the computer.
- 4. Wait for the computer to detect it (about 10 seconds).
- 5. Place the scanner on the base, a series of different sound signals will be heard.
- 6. When the light on the scanner flashes green, scan the following bar codes, another series of different sound signals will be heard.



Restore Defaults



IBM Hand-Held USB

- 7. Wait for the computer to detect it.
- 8. Open ChronoMEDIC Production, normally a message for adding the device should appear, otherwise:
 - a. Go to the Utilities tab.
 - b. CONFIGURATION button, then USB button.
 - c. Click on the new device and scan your employee card, it should appear in the square at the bottom.
 - d. Go to the Consultation tab.
 - e. HISTORY (tray or product).
 - f. Scan your employee card.
 - i. Check that an error message is displayed (ex.: Product xxx doesn't exist).
- 9. IMPORTANT: disable power management on the computer the scanner is plugged into, otherwise it will not recharge when ChronoMEDIC Production is not open.
 - a. Manual procedure: https://www.nbautomation.com/wp-content/uploads/2018/07/DS2278-disable-power-management.pdf
 - b. VBS script to automatically disable:
 https://supportcommunity.zebra.com/s/article/Barcode-scanners-do-not-recharge-in-Windows-10-if-set-to-IBM-handheld-IBM-TT-Opos?language=en">https://supportcommunity.zebra.com/s/article/Barcode-scanners-do-not-recharge-in-Windows-10-if-set-to-IBM-handheld-IBM-TT-Opos?language=en">https://supportcommunity.zebra.com/s/article/Barcode-scanners-do-not-recharge-in-Windows-10-if-set-to-IBM-handheld-IBM-TT-Opos?language=en">https://supportcommunity.zebra.com/s/article/Barcode-scanners-do-not-recharge-in-Windows-10-if-set-to-IBM-handheld-IBM-TT-Opos?language=en">https://supportcommunity.zebra.com/s/article/Barcode-scanners-do-not-recharge-in-Windows-10-if-set-to-IBM-handheld-IBM-TT-Opos?language=en">https://supportcommunity.zebra.com/s/article/Barcode-scanners-do-not-recharge-in-Windows-10-if-set-to-IBM-handheld-IBM-TT-Opos?language=en">https://supportcommunity.zebra.com/s/article/Barcode-scanners-do-not-recharge-in-Windows-10-if-set-to-IBM-handheld-IBM-TT-Opos?language=en">https://supportcommunity.zebra.com/s/article/Barcode-scanners-do-not-recharge-in-Windows-10-if-set-to-IBM-handheld-IBM-TT-Opos?language=en">https://supportcommunity.zebra.com/s/article/Barcode-scanners-do-not-recharge-in-Windows-10-if-set-to-IBM-handheld-IBM-TT-Opos?language=en">https://supportcommunity.zebra.com/s/article/Barcode-scanners-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Windows-do-not-recharge-in-Win